



X AIR Mixer Firmware Version 1.18 - (01 October 2021)

The X AIR Firmware Update V 1.18 includes performance enhancements to your Behringer X AIR mixer's operating system. BEHRINGER is constantly adding new features and making enhancements to this extremely stable operating system, so that you always experience the best possible performance from your X AIR Mixer. Check out [behringer.com](https://www.behringer.com) for updates regularly.

Note: You can use the X AIR EDIT application for PC (Win/Mac/Linux) for updating your X AIR mixer firmware. Download and unpack the correct update file from [behringer.com](https://www.behringer.com), and connect your PC with your X AIR mixer in the same (wired or wireless) network.

- *XR18_firmware_master-1.18-20210909.update* to be used with Behringer X18 and XR18 mixers
- *XR12_firmware_master-1.18-20210909.update* to be used with Behringer XR12 and XR16 mixers

Then open the X AIR EDIT Setup/Connection page and select your X AIR mixer from the list box. The current firmware version installed on your mixer will be displayed right below the list box. Click on 'Update FW', select the update file and click 'Open'. After the firmware has been installed successfully and the mixer is rebooted, you can connect the EDIT app to it and synchronize as usual.

Please note: It is generally recommended to save important settings as scenes or presets on your control device, before updating the firmware.

This new firmware version includes:

New Features

- n/a

Improvements

- Fixed memory issue with long up-times of remote connection
- Improved resilience against incorrect OSC meter requests

Behringer is constantly adding new features and making enhancements to this extremely stable ecosystem of digital mixers. This means you always experience the best possible performance.

Visit [behringer.com](https://www.behringer.com) and check for updates of your products regularly.