Quick Start Guide

iW 62 BACKCAN

Pre-Install backcan for iW 62DS-WH and iW 62S-WH In-Wall Loudspeakers

IN WALL INSTALLATION

- Using screws that are at least ¾" long, affix backcan to studs or joists. Tannoy recommends a minimum of 8 screws.
- 2 Run appropriate gauge and type of wire for your particular installation to the backcan location. 1/2" or 3/4" conduit is also an option.
- Install a suitable connector for wire chosen into the ½" or ¾" knock out. Run wire through connector, leaving enough length to reach the loudspeaker with excess for ease of connection.
- 4 Leave excess wire in the backcan until drywall or desired finishing is complete.
- The flange on the front of the backcan will protrude through the drywall and act as a guide for drywall installation.
- After desired finishing is complete, connect the previous installed wire in the backcan to the red (+) and black (-) terminals on the chosen loudspeaker model. An optional ground wire may be used to reduce RF interference.
- **7** Follow installation instructions found in the loudspeaker quick start quide for final speaker installation.

For technical assistance: Tannoy UK +44 1562 732290 or visit our website at *tannoy.com*.



Alignment tags for in wall mounting

LEGAL DISCLAIMER

Music Tribe accepts no liability for any loss which may be suffered by any person who relies either wholly or in part upon any description, photograph, or statement contained herein. Technical specifications, appearances and other information are subject to change without notice. All trademarks are the property of their respective owners. Midas, Klark Teknik, Lab Gruppen, Lake, Tannoy, Turbosound, TC Electronic, TC Helicon, Behringer, Bugera and Coolaudio are trademarks or registered trademarks of Music Tribe Global Brands Ltd. © Music Tribe Global Brands Ltd. 2018 All rights reserved.

LIMITED WARRANTY

 $For the applicable \ warranty, please see complete \ details \ online \ at \ music tribe. com/warranty.$





