

S32 Firmware Update

Version 1.8 - (30 September 2020)

This document provides information on the firmware update 1.8 for the Behringer S32 Stagebox. Version 1.8 for S32 enables to forward DP48 Messages via AES50 when daisy chaining multiple devices. The firmware update can easily be done via USB using a Windows PC/laptop computer. Please follow the update instructions at the end of this document.

This new S32 Firmware version contains:

New Features

- Forwarding of DP48 Messages via AES50

Improvements

- n/a

Requirements:

Behringer X32 / Midas M32 series console firmware 4.02 or higher recommended for optimal use with S32 firmware 1.8.

Windows (10, 7 or 8.1) PC with USB connector and administrator account required for running the updater executable (s32update_1-8.exe).

Behringer is constantly adding new features and making enhancements to this extremely stable ecosystem of digital mixers, I/O boxes and personal monitoring mixers. This means you always experience the best possible performance.

Visit [behringer.com](https://www.behringer.com) and check for updates of your products regularly.

Update Process:

1. Download and unpack the updater zip file from [behringer.com](https://www.behringer.com) on your Windows PC
2. While the S32 is switched off, connect its USB port to your PC using a standard USB cable (type A -- type B)
3. Upon powering up, the S32 will detect the USB connection and wait for the update
4. Make sure you have started your Windows session with Administrator access, then start the `s32update_1-8.exe`
5. The terminal window will inform you about the update progress.
Wait approximately 1 min until it shows completed
6. Disconnect the USB link and switch the S32 power off / on