


## Firmware update instructions for the Lab.gruppen NLB 60E NomadLink Bridge and Network Controller


1. Extract download (.zip-file) to a common location on your PC, such as a folder on the desktop.
2. Make sure the NLB 60E is connected to the computer in the manner described in the NLB 60E Operation Manual.
3. Run the NLB 60E BridgeUpdater.exe program received in the download.
4. The NLB 60E unit(s) will be detected and displayed in the BridgeUpdater application window.



5. Press "Browse" and selected the .bin-file (received in the download). Press Open button.

6. Select an NLB 60E and press the Update button. Updating can take 3 to 4 minutes.

Status of the update process will be displayed in the Info field and with a progress bar.



**IMPORTANT!** Do not turn power off or disconnect Ethernet connection before you see this pop-up window:



7. Repeat step 6 until all NLB 60E units are updated.
8. Run DeviceControl to test access to the updated NLB 60E unit(s).

Refer to the NLB 60E Operation Manual for more detailed information.

It is available online at [www.labgruppen.com](http://www.labgruppen.com) under support/software\_firmware