

Quick Start Guide

TC ELECTRONIC HELIX PHASER

USB - Connects to your computer for firmware updates and TonePrint editing.

Power Input - Connect a 9V / >100 mA power supply.

Speed - Controls the speed of the phaser effect.

Depth - Controls the intensity of the phaser effect.

Feedback - Controls the amount of signal fed back into the phaser input.

Phaser Type - Choose between Vintage, TonePrint and Smooth settings.

Mix - Controls the amount of effected signal added to your sound.

Output

Input

Footswitch - Turns the effect on and off.



Visit tcelectronic.com to download the full manual